

General Instruction Sheet

Busts with and without stands

Fixing bust cover and cap

Step 1 – Position the bust upright and begin to pull the bust cover down and over the bust. Be sure to begin with the widest section of the cover and at the top of the bust.

Tip – To remove any creases or folds in the cover, fold any excess cover into the void at the top of the neck and stretch the cover down and over the bust. Now tighten the drawstring at the bottom of the cover and tuck the excess string into the hole(s) on the bottom of the bust (without fixture).

Step 2 – With the excess cover folded into the neck begin to push the neck cap into the same void (if you have the Hanging bust cap screw into place).



For Busts with Low Stands...

Step 1 – Gather the base and upright pole and begin to screw these together.

Tip – Be sure to remove both the protective film from the base and the rubber cap from the upright pole before beginning construction.

Step 2 - Now position the bust up onto the stand and using the fastener on the base of the bust fix at the desired height.



For Busts with High Stands...

Step 1 – Gather the base and upright pole and begin to screw these together. To increase the height of your bust, simply clip the included extension bar into the top of the upright pole.

Tip – Be sure to remove both the protective film from the base and the rubber cap from the upright pole before beginning construction. Make sure that the plastic button has popped out into position.

Step 2 - Now position the bust up onto the stand and using the fastener on the base of the bust fix at the desired height. You have an option to use either a side or central fixing point, allowing the bust to wear trousers, shorts, dresses etc - dependant on bust.



General Instruction Sheet

Busts with and without stands

For Busts with a Curved Stand...

Step 1 – Gather the base and upright pole and begin to screw these together. With the first half of the stand assembled insert the second half of the upright pole and tighten the socket screws located on the back of both upright poles.

Tip – Be sure to remove both the protective film from the base and the rubber cap from the upright pole before beginning construction.

Step 2 - To position the bust, simply lift it up, locate the recess at the top of the stand and hoop into position.



You can also buy spares and accessories at www.Displaysense.co.uk

Below is a list of all our Bust components followed by images of each -

FG2603 - Bust Stand - **HIGH**

FG2620PG - Bust Stand - **CURVED**

FG2601 - Bust Stand - **LOW**

FG2401 - Bust Cap - **GREY**

FG2402G - Bust Hanging Cap - **Grey**

FG2001 - Female Bust - **Full Length**

FG2002 - Female Bust - **Medium Length**

FG2020 - Male Bust - **Medium Length**

FG2301 - Natural Cover - for **FG2001**

FG2201 - Grey Cover - for **FG2001**

FG2390 - Black Cover - for **FG2001**

FG2302 - Natural Cover - for **FG2002**












FG2202 - Grey Cover - for **FG2002**

FG2391 - Black Cover - for **FG2002**

FG2320 - Natural Cover - for **FG2020**

FG2220 - Grey Cover - for **FG2020**

FG2393 - Black cover - for **FG2020**

	Female Bust Full Length	Female Bust Medium Length	Male Bust Medium Length
BUSTS			
COVERS	Covers for Full Length Female Bust	Covers for Medium Length Female Bust	Covers for Medium Length Male Bust
	 <ul style="list-style-type: none"> ◀ Grey FG2201 ◀ Natural FG2301 ◀ Black FG2390 	 <ul style="list-style-type: none"> ◀ Grey FG2202 ◀ Natural FG2302 ◀ Black FG2391 	 <ul style="list-style-type: none"> ◀ Grey FG2220 ◀ Natural FG2320 ◀ Black FG2393
STANDS	Bust Stand - Low	Bust Stand - High	Bust Stand - Curved
			
CAPS	Bust Cap - Grey		Bust Hanging Cap - Grey (to be used with curved stand)
			

To order your Busts, components, spares go to www.DisplaySense.co.uk